

FIG. 1A




FIG. 1B




FIG. 1C




FIG. 1D




FIG. 2A




FIG. 2B




FIG. 2C




FIG. 2D




FIG. 3




FIG. 4




FIG. 5A




FIG. 5B






FIG. 6A

FIG. 6B





FIG. 6C




FIG. 7A




FIG. 7B




FIG. 7C

802





FIG. 8

116a

116b

116



Gear structure of central hinge




FIG. 10A




FIG. 10B




FIG. 11




FIG. 12A




FIG. 12B




FIG. 13






FIG. 14




FIG. 15




FIG. 16




FIGURE 17

( Bluetooth Adapter for  
Actixys Universal Keyboard )




FIG. 18




FIG. 19A




FIG. 19B




FIG. 20






FIG. 21A







FIG. 21B (w/o top cover)



The top cover and the backplate mechanical wire frame




The mechanical outlook for the top cover and the backplate



Battery Box

FIG. 21C (w/ top cover)

FIG. 22






FIG. 23 A




FIG. 23 B